

Memorandum

Date: September 18, 2020
To: BASMAA Monitoring and Pollutants of Concern Committee
From: Lisa Austin, Principal, and Kelly Havens, Senior Engineer
Subject: PCBs in Building Materials Management Program – Regional Data Summary
Geosyntec Project Number: LA0597/CWR0609

1. BACKGROUND

Municipal Regional Stormwater Permit (MRP; Order No. R2-2015-0049) Provision C.12.f requires Permittees to manage PCBs-containing materials and wastes during building demolition activities. The MRP Permittees have developed and implemented a process, beginning in July 2019, for managing materials with PCBs concentrations of 50 ppm or greater in applicable structures at the time applicable structures undergo demolition. Applicable structures include commercial, public, institutional, and industrial buildings constructed or remodeled between the years 1950 and 1980 undergoing full-building demolition. Single-family residential and wood frame structures are exempt.

This technical memorandum documents the following items as required by MRP Provision C.12.f.iii.(4):

- a. The number of applicable structures that applied for a demolition permit during the reporting year; and
- b. A running list of the applicable structures that applied for a demolition permit (since the date the PCBs control protocol was implemented) that had material(s) with PCBs at 50 ppm or greater, with the address, demolition date, and brief description of PCBs control method(s) used.

This memorandum was developed by the countywide stormwater management programs in the MRP area working together through the Bay Area Stormwater Management Agencies Association (BASMAA) Monitoring and Pollutants of Concern (MPC) Committee (via an informal regional collaboration).

2. NUMBER OF APPLICABLE STRUCTURE APPLICATIONS

The number of applicable structures that applied for a demolition permit during Fiscal Year 2019/20 (i.e., from July 1, 2019 – June 30, 2020), as well as the number of samples in those buildings that were equal to or greater than 50 ppm, is summarized in Table 1 below.

A list providing the same information, but for each Permittee, is provided in Attachment 1.

Table 1: Number of Applicable Structure Applications Received in FY 2019/20

County	# Applicable Applications	# Samples ≥ 50 ppm PCBs
Alameda	26	23
Contra Costa	3	6
San Mateo	12	3
Santa Clara	37	8
Solano	5	0
Total	83	40

3. LIST OF APPLICABLE STRUCTURES

A running list of the applicable structures that applied for a demolition permit since July 1, 2019 that had materials with PCBs at 50 ppm or greater, with the address and estimated demolition date, is provided in Attachment 2.

4. DESCRIPTION OF PCBs CONTROL METHOD

4.1 Permittee Control Method

On behalf of MRP Permittees, the BASMAA conducted a Regional Project that developed an implementation framework, guidance materials, and tools for local agencies to ensure that PCBs-containing materials and wastes are properly managed during building demolition; these materials are provided in Attachment 3. The Regional Project also provided training materials and a workshop for municipal staff and an outreach workshop for the industry on implementing the framework/protocols developed via the project.

Permittees have implemented the following process for this control measure:

- The municipality informs applicable demolition permit applicants that their projects are subject to the program for managing materials with PCBs, necessitating, at a minimum, an initial screening for priority PCBs-containing materials.

- For every applicable demolition project, applicants implement the BASMAA protocol for identifying building materials with PCBs concentrations of 50 ppm or greater and then complete and submit a version of BASMAA’s model “PCBs Screening Assessment Form” (Screening Form) or equivalent to the municipality.
- The municipality reviews the Screening Form to make sure it is filled out correctly and is complete and works with the applicant to correct any deficiencies.
- The municipality then issues the demolition permit or equivalent, according to its procedures.
- The municipality sends each completed Screening Form for applicable structures and any supporting documents to its countywide program. The countywide program compiles the forms and works with the other MRP countywide programs to manage and evaluate the data, and to assist Permittees with associated MRP reporting requirements.

4.2 Building Demolition Applicant Control Method

Applicants that determine, through implementation of the BASMAA protocol, that PCBs exist in priority building materials must follow applicable federal and state laws for handling and disposal. This may include reporting to U.S. Environmental Protection Agency (USEPA), the San Francisco Bay Regional Water Quality Control Board, and the California Department of Toxic Substances Control (DTSC). These agencies may require additional sampling and abatement of PCBs.

Depending on the approach for sampling and removing building materials containing PCBs, the applicant may need to notify or seek advance approval from USEPA before building demolition. Even in circumstances where advance notification to or approval from USEPA is not required before the demolition activity, the disposal of PCBs waste is regulated under Toxic Substances Control Act (TSCA). For example, TSCA requires manifesting the waste for transportation and disposal. (See 40 Code of Federal Regulations (CFR) 761 and 40 CFR 761, Subpart K.) TSCA-regulated does not equate solely to materials containing PCBs at or above 50 ppm. There are circumstances in which materials containing PCBs below 50 ppm are subject to regulation under TSCA. (See 40 CFR 761.61(a)(5)(i)(B)(2)(ii).). 40 CFR 761.3 provides information relative to disposal of PCBs-containing building materials, including definitions of PCBs bulk product wastes and PCBs remediation wastes. Further information is provided in a memorandum “PCB Bulk Product Waste Reinterpretation” from the Office of Resource Conservation and Recovery, EPA¹.

¹ Located here: https://www.epa.gov/sites/production/files/2016-01/documents/wste-memo_102412.pdf.

Additionally, the disposal of PCBs waste is subject to California Code of Regulations (CCR) California Code of Regulations (CCR) Title 22, Section Division 4.5, Chapter 12, Standards Applicable to Hazardous Waste Generators.

Attachment 1
Number of Applicable Structure Applications by
Permittee

Permittee	# Applicable Applications	# Samples ≥ 50 ppm PCBs
Alameda	0	0
Albany	0	0
Berkeley	0	0
Dublin	0	0
Emeryville	0	0
Fremont	2	1
Hayward	2	3
Livermore	0	0
Newark	0	0
Oakland	21	19
Piedmont	0	0
Pleasanton	0	0
San Leandro	1	0
Union City	0	0
Alameda County	0	0
Alameda County Total	26	23
Clayton	Exempt	Exempt
Concord	1	6
Danville	0	0
El Cerrito	0	0
Hercules	0	0
Lafayette	0	0
Martinez	0	0
Moraga	0	0
Orinda	0	0
Pinole	0	0
Pittsburg	0	0
Pleasant Hill	0	0
Richmond	2	0
San Pablo	0	0
San Ramon	0	0
Contra Costa County	0	0
Walnut Creek	0	0
Contra Costa County Total	3	6
Campbell	0	0
Cupertino	0	0
Los Altos	0	0

Permittee	# Applicable Applications	# Samples ≥ 50 ppm PCBs
Los Altos Hills	0	0
Los Gatos	0	0
Milpitas	0	0
Monte Sereno	0	0
Mountain View	2	0
Palo Alto	2	4
San Jose	4	0
Santa Clara	1	0
Santa Clara County	0	0
Saratoga	0	0
Sunnyvale	28	4
Santa Clara County Total	37	8
Atherton	0	0
Belmont	0	0
Brisbane	0	0
Burlingame	1	0
Colma	0	0
Daly City	0	0
East Palo Alto	0	0
Foster City	0	0
Half Moon Bay	0	0
Hillsborough	0	0
Menlo Park	1	1
Millbrae	0	0
Pacifica	0	0
Portola Valley	0	0
Redwood City	1	0
San Bruno	0	0
San Carlos	1	0
San Mateo	0	0
San Mateo County	1	0
South San Francisco	6	2
Woodside	1	0
San Mateo County Total	12	3
City of Vallejo	5	0
City of Fairfield	0	0
Suisun City	0	0

Permittee	# Applicable Applications	# Samples \geq 50 ppm PCBs
Solano County Total	5	0
MRP Permittee Regional Total	83	40

Attachment 2
Number of Applicable Structure Applications by
Permittee with PCBs at 50 ppm or Greater


Program	Permittee	Building ID	Address	Estimated Demo Date	# Samples ≥ 50 ppm PCBs	PCBs Concentration Range (mg/kg)
ACCWP	Oakland	AC - 14	5441 International Boulevard, Oakland, CA, 94601	June 2020	5	54 - 174
ACCWP	Oakland	AC - 15	5441 International Boulevard, Oakland, CA, 94601	June 2020	1	139.4
ACCWP	Oakland	AC - 16	5441 International Boulevard, Oakland, CA, 94601	June 2020	2	66.1 - 85
ACCWP	Oakland	AC - 17	5441 International Boulevard, Oakland, CA, 94601	June 2020	1	56
ACCWP	Oakland	AC - 18	5441 International Boulevard, Oakland, CA, 94601	June 2020	2	53 - 64
ACCWP	Oakland	AC - 19	5441 International Boulevard, Oakland, CA, 94601	June 2020	1	61
ACCWP	Oakland	AC - 21	5441 International Boulevard, Oakland, CA, 94601	June 2020	2	58 - 104
ACCWP	Oakland	AC - 26	5441 International Boulevard, Oakland, CA, 94601	June 2020	1	125
ACCWP	Oakland	AC - 31	7200 Earhart Rd, Oakland, CA, 94621	November 2019	4	190 - 537,000
ACCWP	Fremont	AC -32	39150 Fremont Bank, Fremont, CA, 94539	Jan 2020	1	50
ACCWP	Hayward	AC -34	22300 City Center Drive, Hayward, CA, 94541	April 2020	3	66 - 9,600
CCCWP	Concord	CCC-01	2292 Concord Blvd, Concord, CA, 94520	May 2020	6	140-550
SCVURPPP	Palo Alto	SC-005	180 El Camino Real, Palo Alto, CA, 94304	March 2020	4	676 - 14,250
SCVURPPP	Sunnyvale	SC-028	650 Vaqueros Ave, Sunnyvale, CA, 94085	July 2020	1	1,100
SCVURPPP	Sunnyvale	SC-031	525 Del Rey Ave, Sunnyvale, CA, 94085	July 2020	2	490 - 630
SCVURPPP	Sunnyvale	SC-043	390 Caribbean Dr., Sunnyvale, CA 94089	Unknown	1	91
SMCWPPP	Menlo Park	SMC-2	305 Constitution Dr., Menlo Park, CA, 94025	Jan 2020	1	54.5
SMCWPPP	South San Francisco	SMC-6	1 Chestnut Avenue, South San Francisco, CA, 94080	Jan 2020	2	247

Attachment 3
PCBs in Priority Building Materials: Model
Screening Assessment Applicant Package

PCBs in Priority Building Materials: Model Screening Assessment Applicant Package



Managing PCBs–Containing Building Materials during Demolition: Guidance, Tools, Outreach and Training



August 2018 (Revised
July 2, 2019)

This document is a deliverable of the Bay Area Stormwater Management Agencies Association (BASMAA) project *Managing PCBs–Containing Building Materials during Demolition: Guidance, Tools, Outreach and Training*. BASMAA developed guidance, tools, and outreach and training materials to assist with San Francisco Bay Area municipal agencies’ efforts to address the requirements of Provision C.12.f. of the Bay Area Municipal Regional Stormwater Permit (referred to as the MRP). Provision C.12.f of the MRP requires Permittees to manage PCBs–containing building materials during demolition.

We gratefully acknowledge the BASMAA Steering Committee for this project, which provided overall project oversight, including during the development of this and other project deliverables:


- Reid Bogert, Stormwater Program Specialist, San Mateo Countywide Water Pollution Prevention Program (BASMAA Project Manager)
- Amanda Booth, Environmental Program Analyst, City of San Pablo
- Kevin Cullen, Program Manager, Fairfield-Suisun Urban Runoff Management Program
- Matt Fabry, Program Manager, San Mateo Countywide Water Pollution Prevention Program
- Gary Faria, Supervisor, Inspection Services, Building Inspection Division, Contra Costa County
- Napp Fukuda, Deputy Director - Watershed Protection Division, City of San José
- Ryan Pursley, Chief Building Official, Building Division, City of Concord
- Pam Boyle Rodriguez, Manager, Environmental Control Programs – Stormwater, City of Palo Alto
- Jim Scanlin, Program Manager, Alameda Countywide Clean Water Program
- Melody Tovar, Regulatory Programs Division Manager, City of Sunnyvale

We also gratefully acknowledge the project Technical Advisory Group, which provided feedback from a variety of project stakeholders during development of selected project deliverables:

Stakeholder Group	Representative(s)
Regulatory – stormwater/PCBs	Luisa Valiela and Carmen Santos, U.S. EPA Region 9
Regulatory – stormwater/TMDL	Jan O’Hara, San Francisco Bay Regional Water Quality Control Board
Regulatory – experience with related program (asbestos management)	Ron Carey and Richard Lew, Bay Area Air Quality Management District
Industry – demolition contractors	Avery Brown, Ferma Corporation
Industry – remediation consultants	John Martinelli, Forensic Analytical Consulting John Trenev, Bayview Environmental Services, Inc.
MRP Permittee – large municipality	Patrick Hayes, City of Oakland
MRP Permittee – medium municipality	Kim Springer, San Mateo County Office of Sustainability
MRP Permittee – small municipality	Amanda Booth, City of San Pablo

Prepared for:

BASMAA
P.O. Box 2385
Menlo Park, CA 94026



Prepared by:

EOA, Inc.
Larry Walker Associates
Geosyntec Consultants
Stephanie Hughes
David J. Powers & Associates, Inc.



PCBs in Priority Building Materials: Model Screening Assessment Applicant Package

Contents

DISCLAIMER	iv
Process Overview	1
Applicant Instructions for Completing the PCBs Screening Assessment Form	2
Part 1. Owner and project information	2
Part 2. Is building subject to the screening requirement based on type, use, and age of the building?	2
Part 3. Report concentrations of PCBs in priority building materials	3
Part 4. Certification.....	4
Notices to Applicants Regarding Federal and State PCBs Regulations	5
Agency Contacts	6
Attachment A Process Flow Chart.....	A-1
Attachment B PCBs in Priority Building Materials Screening Assessment Form	B-1
Attachment C Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition	C-1

DISCLAIMER

Information contained in BASMAA products is to be considered general guidance and is not to be construed as specific recommendations for specific cases. BASMAA is not responsible for the use of any such information for a specific case or for any damages, costs, liabilities or claims resulting from such use. Users of BASMAA products assume all liability directly or indirectly arising from use of the products.

The material presented in this document is intended solely for the implementation of a municipal regulatory program required by the San Francisco Bay Area Regional Water Quality Control Board Municipal Regional Stormwater Permit for the protection of water quality under the Clean Water Act.

BASMAA prepared the tools and guidance herein to assist MRP Permittees' efforts to address the requirements of Provision C.12.f. of the MRP. The project team received input from a variety of stakeholders during development of the tools and guidance, including regulators (San Francisco Bay Regional Water Quality Control Board, U.S. EPA, and Bay Area Air Quality Management District staff), Bay Area municipal agency staff, and industry representatives.

This document does not address other environmental programs or regulations (e.g., PCBs regulations under the Toxic Substances Control Act (TSCA); federal, state, or local regulations for hazardous material handling and hazardous waste disposal; health and safety practices to mitigate human exposure to PCBs or other hazardous materials; recycling mandates; and abatement at sites with PCBs (or other contaminants). The applicant is responsible for knowing and complying with all relevant laws and regulations.

The mention of commercial products, their source, or their use in connection with information in BASMAA products is not to be construed as an actual or implied approval, endorsement, recommendation, or warranty of such product or its use in connection with the information provided by BASMAA.

This disclaimer is applicable to all BASMAA products, whether information from the BASMAA products is obtained in hard copy form, electronically, or downloaded from the Internet.

Process Overview

This document provides a model PCBs in Priority Building Materials Screening Assessment process to be conducted by demolition project proponents (applicants). A flow chart illustrating the above processes is provided in **Attachment A**.

Applicants proposing to demolish buildings must conduct the PCBs screening assessment. Through the PCBs screening assessment applicants will:

- 1) Determine whether the building proposed for demolition is likely to have PCBs-containing building materials (see discussion of applicable structure); and
- 2) Determine whether PCBs are present at a concentration equal to or greater than 50 parts per million (ppm) in building materials.

Use the *PCBs Screening Assessment Form (Attachment B)* to summarize and certify the information required by the municipality to issue the demolition permit. The form is divided into four parts:

- **Part 1** provide applicant information and project location.
- **Part 2** complete the questions to identify whether the project involves an applicable structure. If the demolition does not involve an applicable structure, the form may be certified and submitted without completing Part 3.
- **Part 3** complete the questions to provide the concentrations of PCBs in any priority building materials.
- **Part 4** certify the information being submitted.

Note that fluorescent light ballasts, polyurethane foam furniture, and Askarel fluid used in transformers, all of which may contain PCBs, are typically managed during pre-demolition activities under current regulations and programs that require removal of universal waste and outdated transformers. For this process it is assumed that those materials will be evaluated and managed under those existing programs.

This screening process is part of a program for water quality protection and was designed in accordance with requirements in the MRP. ¹ It does not address other environmental programs or regulations (e.g., PCBs regulations under the Toxic Substances Control Act (TSCA); federal, state, or local regulations for hazardous material handling and hazardous waste disposal; health and safety practices to mitigate human exposure to PCBs or other hazardous materials; recycling mandates; or abatement at sites with PCBs (or other contaminants). **The applicant is responsible for complying with all relevant laws and regulations. See the Notices to Applicants section for additional information.**

Water quality within the San Francisco Bay Region is regulated by the San Francisco Bay Area Regional Water Quality Control Board (Regional Water Board).

In 2015, the Regional Water Board reissued the Municipal Regional Permit (MRP)¹ that regulates discharges of stormwater runoff. The MRP includes provisions for reducing discharges of polychlorinated biphenyls (PCBs) in stormwater runoff and requires municipalities to develop a program to manage priority PCBs-containing building materials during demolition and implement the program by July 1, 2019.

Existing federal and state regulations create the framework for managing PCBs in building materials once those PCBs are identified through this program and for disposing of wastes containing PCBs.

¹ A National Pollutant Discharge Elimination System (NPDES) permit, Order No. R2-2015-0049, issued to municipalities in the counties of Alameda, Contra Costa, San Mateo, and Santa Clara, and the Cities of Fairfield, Suisun City, and Vallejo.

Applicant Instructions for Completing the PCBs Screening Assessment Form

Applicants for demolition permits or other permits that involve the complete demolition of a building must conduct an assessment to screen for PCBs in priority building materials. Use the *PCBs Screening Assessment Form*, to summarize and certify the information needed by the municipality to issue a demolition permit. The form is provided in **Attachment B**. If the project includes the demolition of multiple buildings complete one form for each building to be demolished.

Part 1. Owner and project information

Complete the owner and consultant information and the project location information.

For the Type of Construction select one of the following options:

- **Wood Frame** (Buildings constructed with lumber or timbers, which make up the studs, plates, joists, and rafters.)
- **Masonry Construction** (Buildings constructed with concrete blocks or bricks as the load bearing walls typically with the floors and ceilings constructed with wooden joists.)
- **Steel Frame Construction** (Buildings constructed with steel studs or steel columns and steel joists or trusses to support floors and roofs. Includes light gauge steel construction and high-rise steel construction.)
- **Concrete Frame** (Buildings constructed with reinforced concrete columns, concrete beams, and concrete slabs.)
- **Pre-Engineered** (Buildings constructed with pre-engineered parts bolted together.)

Part 2. Is building subject to the screening requirement based on type, use, and age of the building?

Part 2 documents the determination of whether the proposed demolition will affect an applicable structure. If the demolition does not affect an applicable structure, then the assessment is complete, and the form can be certified.

This determination screens out buildings that are a lower priority with regard PCBs-containing materials and provides an off-ramp from the rest of the screening process.

Key Definitions

Demolition means the wrecking, razing, or tearing down of any building. The definition is intended to be consistent with the demolition activities undertaken by contractors with a C-21 Building Moving/Demolition Contractor's License.

Priority Building Materials are:

1. Caulk;
2. Thermal insulation;
3. Fiberglass insulation;
4. Adhesive mastics; and
5. Rubber window gaskets.

Buildings are structures with a roof and walls standing more or less permanently in one place. Buildings are intended for human habitation or occupancy.

Applicable Structures are defined as buildings constructed or remodeled between January 1, 1950 and December 31, 1980. Wood framed buildings and single-family residential buildings are not applicable structure regardless of the age of the building.

Question 2.a: Is the building to be demolished wood framed and/or single family residential?

- If YES the PCBs Screening Assessment is complete, skip to the certification in Part 4.
- If NO, continue to Question 2.b.

Question 2.b: Was the building to be demolished constructed or remodeled between January 1, 1950 and December 31, 1980?

- If YES continue to Question 2.c.
- If NO, the PCBs Screening Assessment is complete, skip to the certification in Part 4.

Question 2.c: Is the proposed demolition a complete demolition of the building (as defined in key definitions of this document)?

- If YES continue to Part 3.
- If NO, the PCBs Screening Assessment is complete, skip to the certification in Part 4.

Studies have found the highest concentrations of PCBs in building materials in buildings that were built or remodeled from 1950 to 1980.

For this process, the date that the building permit was issued will be used to determine applicability.

Part 3. Report concentrations of PCBs in priority building materials

Part 3 documents the results of the assessment of PCBs concentrations in priority building materials. Part 3 is only required for proposed demolition of an applicable structure, as determined in Part 2. Check the option used.

- **Option 1** Conduct representative sampling and analysis of the priority building materials per the *Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition* (August 2018) provided in **Attachment C**.
- **Option 2** Use existing sampling results of the priority building materials. Applicants who have conducted sampling prior to the publication of the protocol may use that data provided it is consistent with the protocol (e.g., analytical methods, sample collection frequency, QA/QC). It is anticipated that prior sampling results will rarely be available and that most Applicants will need to use Option 1.

3.a Option 1 – Conduct representative sampling

Check this box if you conducted representative sampling and analysis of the priority building materials per the *Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition* (August 2018) (**Attachment C**).

- Complete the applicable tables for each priority building material.
- Attach the contractor's report² documenting the evaluation results.
- Attach (or include in the contractor's report) the QA/QC checklist (see **Attachment C**, Section 3.2.4).
- Attach copies of the analytical data reports.

² The contractor's report of the findings of the PCBs building material evaluation. See section 3 of Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition (Attachment C).

3.a Option 2 – Use existing sampling records

In some cases, a property owner may have conducted sampling of the priority building materials for PCBS. If such data exist, you may use these data to demonstrate the concentration of PCBs in the priority building materials for the PCBs screening. However, if the sampling must be consistent with the *Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition*.

- Complete the applicable tables for each priority building material.
- Attach the contractor's report/statement that the results are consistent with the *Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition*.
- Attach copies of the analytical data reports.

Part 3 Tables Summarize concentrations of PCBs in priority building materials

Use these tables to summarize the concentrations of PCBs in the priority building materials.

- Each page of the table is for a different material. Duplicate the pages as needed to report all concentration data.
- A blank page is provided. Applicants have the option of submitting PCBs concentration data on other materials in addition to the priority building materials.

Column 1: required for all priority building material PCBs concentrations

- Use column 1 to report all PCBs concentrations in the priority building materials. Provide short description of the sample location, concentration.

Column 2: only required for PCBs concentrations ≥ 50 ppm

- Use column 2 to estimate the amount of material associated with each sample.

Part 4. Certification

- Complete the certification. The certification must be signed by the property owner or the owner's agent or legal representatives and the consultant who complete the application form.

Notices to Applicants Regarding Federal and State PCBs Regulations

Applicants that determine PCBs exist in priority building materials must follow applicable federal and state laws. This may include reporting to U.S. Environmental Protection Agency (USEPA), the San Francisco Bay Regional Water Quality Control Board, and the California Department of Toxic Substances Control (DTSC). These agencies may require additional sampling and abatement of PCBs.

Depending on the approach for sampling and removing building materials containing PCBs, you may need to notify or seek advance approval from USEPA before building demolition. Even in circumstances where advance notification to or approval from USEPA is not required before the demolition activity, the disposal of PCBs waste is regulated under Toxic Substances Control Act (TSCA).

Additionally, the disposal of PCBs waste is subject to California Code of Regulations (CCR) California Code of Regulations (CCR) Title 22, Section Division 4.5, Chapter 12, Standards Applicable to Hazardous Waste Generators.

Building owners and employers need to consider worker and public safety during work involving hazardous materials and wastes including PCBs.

Federal and State Regulations

See 40 Code of Federal Regulations (CFR) 761.3 for important information relative to disposal of PCBs-containing building materials, including definitions of PCBs bulk product wastes and PCBs remediation wastes. Also see the memorandum dated October 24, 2012 "PCB Bulk Product Waste Reinterpretation" from Suzanne Rudzinski, Director, Office of Resource Conservation and Recovery, EPA.

Disposal of PCBs wastes are subject to TSCA requirements such as manifesting of the waste for transportation and disposal. See 40 CFR 761 and 40 CFR 761, Subpart K.

TSCA-regulated does not equate solely to materials containing PCBs at or above 50 ppm. There are circumstances in which materials containing PCBs below 50 ppm are subject to regulation under TSCA. See 40 CFR 761.61(a)(5)(i)(B)(2)(ii).

Disposal of PCBs wastes are subject to California Code of Regulations (CCR) Title 22, Section Division 4.5, Chapter 12, Standards Applicable to Hazardous Waste Generators.

California hazardous waste regulatory levels for PCBs are 5 ppm based on the Soluble Threshold Limit Concentration test and 50 ppm based on the Total Threshold Limit Concentration test, see CCR, Title 22, Section 66261.24, Table III.


Agency Contacts

Applicants should contact the appropriate agencies and review the relevant guidance and information about PCBs in building materials. Municipal staff are not able to advise you on the requirements of the applicable federal and state laws.

Agency	Contact	Useful Links
US Environmental Protection Agency	Steve Armann (415) 972-3352 armann.steve@epa.gov	https://www.epa.gov/pcbs (EPA PCB website) https://www.epa.gov/pcbs/questions-and-answers-about-polychlorinated-biphenyls-pcbs-building-materials (PCBs in Building Materials Fact Sheet and Q/A Document) https://www.epa.gov/pcbs/pcb-facility-approval-streamlining-toolbox-fast-streamlining-cleanup-approval-process (USEPA PCB Facility Approval Streamlining Toolbox (PCB FAST)) https://www.epa.gov/pcbs/polychlorinated-biphenyls-pcbs-building-materials#Test-Methods (See Information for Contractors Working in Older Buildings that May Contain PCBs)
San Francisco Bay Regional Water Quality Control Board	Jan O'Hara (510) 622-5681 Janet.O'Hara@waterboards.ca.gov Cheryl Prowell (510) 622-2408 Cheryl.Prowell@waterboards.ca.gov	https://www.waterboards.ca.gov/sanfranciscobay/water_issues/programs/TMDLs/sfbaypcbstmdl.shtml https://www.waterboards.ca.gov/sanfranciscobay/water_issues/programs/sitecleanupprogram.html
Department of Toxic Substances Control	Regulatory Assistance Office 1-800-72TOXIC RAO@dtsc.ca.gov	http://www.dtsc.ca.gov/SiteCleanup/Brownfields/upload/PUB_SMP_Guide-to-Selecting-a-Consultant.pdf
California Division of Occupational Safety and Health (known as Cal/OSHA)	CalOSHA Consultations Services 1-800-963-9424	https://www.dir.ca.gov/dosh/consultation.html

Attachment A
Process Flow Chart

PCBs in Priority Building Materials Screening Assessment Process



Note 1

- ❖ Building materials containing PCBs at or above 50 ppm that were manufactured with PCBs (e.g., caulk, joint sealants, paint) fall under the category of PCBs bulk product wastes. See 40 Code of Federal Regulations (CFR) 761.3 for a definition of PCBs bulk product wastes.
- ❖ Building materials such as concrete, brick or metal contaminated with PCBs are PCBs remediation wastes (e.g., concrete contaminated with PCBs from caulk that contains PCBs). 40 CFR 761.3 defines PCBs remediation wastes.
- ❖ Disposal of PCBs wastes are subject to TSCA requirements such as manifesting of the waste for transportation and disposal. See 40 CFR 761 and 40 CFR 761, Subpart K.
- ❖ TSCA-regulated does not equate solely to “materials containing PCBs at or above “50 mg/kg.” There are circumstances in which materials containing PCBs below 50 mg/kg are subject to regulation under TSCA. See 40 CFR 761.61(a)(5)(i)(B)(2)(ii).
- ❖ Disposal of PCBs wastes are subject to California Code of Regulations (CCR) Title 22, Section Division 4.5, Chapter 12, Standards Applicable to Hazardous Waste Generators.
- ❖ California hazardous waste regulatory levels for PCBs are 5 ppm based on the Soluble Threshold Limit Concentration test and 50 ppm based on the Total Threshold Limit Concentration test, see CCR, Title 22, Section 66261.24, Table III.

Attachment B
PCBs in Priority Building Materials Screening
Assessment Form

PCBs Screening Assessment Form

For Municipality Use Only	
Date Received	
File #	

This screening process is part of a program for water quality protection and was designed in accordance with requirements in the Bay Area regional municipal stormwater NPDES permit (referred to as the Municipal Regional Permit). This process **does not** address other environmental programs or regulations (e.g., PCBs regulations under the Toxic Substances Control Act (TSCA); federal, state, or local regulations for hazardous material handling and hazardous waste disposal; health and safety practices to mitigate human exposure to PCBs or other hazardous materials; recycling mandates; or abatement at sites with PCBs or other contaminants). **The applicant is responsible for knowing and complying with all relevant laws and regulations. See Notices to Applicants section in the Applicant Instructions and at the end of this form.**

Complete all applicable parts of the PCBs Screening Assessment Form and submit with your demolition permit application.

All Applicants must complete Part 1 and Part 2.

Part 1. Owner/Consultant and project information		
Owner Information		
Name		
Address		
City	State	Zip
Contact (Agent)		
Phone	Email	
Consultant Information		
Firm Name		
Address		
City	State	Zip
Contact Person		
Phone	Email	
Project Location		
Address		
City	State CA	Zip
APN (s)		
Year Building was Built	Type of Construction	
Estimated Demolition Date		

Part 2. Is building subject to the PCBs screening requirement based on type, use, and age of the building?

2.a Is the building to be demolished wood framed and/or single family residential? Yes No

If the answer to question 2.a is **Yes**, the PCBs Screening Assessment is complete, skip to Part 4. If the answer is **No**, continue to Question 2.b.

2.b Was the building to be demolished constructed or remodeled between January 1, 1950 and December 31, 1980? Yes No

➤ If the answer to Question 2.b is **No** the PCBs Screening Assessment is complete, skip to Part 4. If the answer is **Yes**, continue to Question 2.c.

2.c Is the proposed demolition a complete demolition of the building? Yes No

➤ If the answer to Question 2.c is **No** the PCBs Screening Assessment is complete, skip to Part 4. If the answer is **Yes**, complete Part 3.

All applications affecting applicable structures and demolitions must complete Part 3 and the Part 3 Tables.

Part 3. Report concentrations of PCBs in priority building materials

Option 1. Applicants conducted representative sampling and analysis of the priority building materials per the Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition (2018) (Attachment C).

Option 2. Applicants possess existing sample results that are that are consistent with the Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition (2018) (Attachment C).

3.a Select option and report PCBs concentrations in the priority building materials and the source of data for each of the priority building materials. Provide the required supporting information

Option 1 Conduct Representative Sampling

- Summarize results on Part 3 Tables; and
- Provide the following supporting information:
 - Contractor’s report documenting the assessment results;
 - QA/QC checklist (see Attachment C, section 3.2.4); and
 - Copies of the analytical data reports.

Option 2 Use Existing Sampling Records

- Summarize results on Part 3 Tables; and
- Provide the following supporting information:
 - Contractor’s report/statement that the results are consistent with the Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition.
 - Copies of the analytical data reports.

All Applicants must complete Part 4.

Part 4. Certification

I certify that the information provided in this form is, to the best of my knowledge and belief, true, accurate, and complete. I further certify that I understand my responsibility for knowing and complying with all relevant laws and regulations related to reporting, abating, and handing and disposing of PCBs materials and wastes. I understand there are significant penalties for submitting false information. I will retain a copy of this form and the supporting documentation for at least 5 years.

Signature: _____ Date: _____
 (Property Owner//Agent/Legal Representative)

Print/Type: _____
 (Property Owner/Agent/Legal Representative Name)

Signature: _____ Date: _____
 (Consultant Completing Application Form)

Print/Type: _____
 (Consultant Completing Application Form)

Notices to Applicants Regarding Federal and State PCBs Regulations

Applicants that determine PCBs exist in building materials must follow applicable federal and state laws. This may include reporting to U.S. Environmental Protection Agency (USEPA), the San Francisco Bay Regional Water Quality Control Board, and the California Department of Toxic Substances Control (DTSC). These agencies may require additional sampling and abatement of PCBs. Depending on the approach for sampling and removing building materials containing PCBs, you may need to notify or seek advance approval from USEPA before building demolition. Even in circumstances where advance notification to or approval from USEPA is not required before the demolition activity, the disposal of PCBs waste is regulated under TSCA and the California Code of Regulations. (See Note 1)

Note 1 - Federal and State Regulations

Building materials containing PCBs at or above 50 ppm that were manufactured with PCBs (e.g., caulk, joint sealants, paint) fall under the category of PCBs bulk product wastes. See 40 Code of Federal Regulations (CFR) 761.3 for a definition of PCBs bulk product wastes.

Building materials such as concrete, brick, metal contaminated with PCBs are PCBs remediation wastes (e.g., concrete contaminated with PCBs from caulk that contains PCBs). 40 CFR 761.3 defines PCBs remediation wastes.

Disposal of PCBs wastes are subject to TSCA requirements such as manifesting of the waste for transportation and disposal. See 40 CFR 761 and 40 CFR 761, Subpart K.

TSCA-regulated does not equate solely to materials containing PCBs at or above 50 ppm. There are circumstances in which materials containing PCBs below 50 ppm are subject to regulation under TSCA. See 40 CFR 761.61(a)(5)(i)(B)(2)(ii).

Disposal of PCBs wastes are subject to California Code of Regulations (CCR) Title 22, Section Division 4.5, Chapter 12, Standards Applicable to Hazardous Waste Generators.

California hazardous waste regulatory levels for PCBs are 5 ppm based on the Soluble Threshold Limit Concentration test and 50 ppm based on the Total Threshold Limit Concentration test, see CCR, Title 22, Section 66261.24, Table III.

Agency	Contact	Useful Links
US Environmental Protection Agency	Steve Armann (415) 972-3352 armann.steve@epa.gov	https://www.epa.gov/pcbs (EPA PCBs website) https://www.epa.gov/pcbs/questions-and-answers-about-polychlorinated-biphenyls-pcbs-building-materials (PCBs in Building Materials Fact Sheet and Q/A Document) https://www.epa.gov/pcbs/pcb-facility-approval-streamlining-toolbox-fast-streamlining-cleanup-approval-process (USEPA PCB Facility Approval Streamlining Toolbox (PCB FAST)) https://www.epa.gov/pcbs/polychlorinated-biphenyls-pcbs-building-materials#Test-Methods (See Information for Contractors Working in Older Buildings that May Contain PCBs)
San Francisco Bay Regional Water Quality Control Board	Jan O'Hara (510) 622-5681 Janet.O'Hara@waterboards.ca.gov Cheryl Prowell (510) 622-2408 Cheryl.Prowell@waterboards.ca.gov	https://www.waterboards.ca.gov/sanfranciscobay/water_issues/programs/TMDLs/sfbaypcbstmtl.shtml https://www.waterboards.ca.gov/sanfranciscobay/water_issues/programs/sitecleanupprogram.html
Department of Toxic Substances Control	Regulatory Assistance Office 1-800-72TOXIC RAO@dtsc.ca.gov	http://www.dtsc.ca.gov/SiteCleanup/Brownfields/upload/PUB_SMP_Guide-to-Selecting-a-Consultant.pdf
California Division of Occupational Safety and Health (Cal/OSHA)	CalOSHA Consultations Services 1-800-963-9424	https://www.dir.ca.gov/dosh/consultation.html

Part 3 Caulk Applications Table

Column 1. Report all PCBs concentrations for each homogenous area of caulking area (see Attachment C, Section 3.2.2). Use sample designators/descriptions from laboratory report.

Column 2. Complete for each concentration ≥ 50 ppm

<u>Caulk Application Sample Description</u>	<u>Concentration (mg/kg)</u>	<u>Estimate Amount of Material</u>	<u>Units</u>
<i>Example:</i>			
<i>Caulk Sample 1</i>	320	48	Linear Feet
1. _____	_____	_____	Linear Feet
2. _____	_____	_____	Linear Feet
3. _____	_____	_____	Linear Feet
4. _____	_____	_____	Linear Feet
5. _____	_____	_____	Linear Feet
6. _____	_____	_____	Linear Feet
7. _____	_____	_____	Linear Feet
8. _____	_____	_____	Linear Feet
9. _____	_____	_____	Linear Feet
10. _____	_____	_____	Linear Feet

Duplicate page if additional space is needed.

Part 3 Fiberglass Insulation Applications Table

Column 1. Report all PCBs concentrations for each homogenous area of fiberglass insulation (see Attachment C, Section 3.2.2). Use sample designators/descriptions from laboratory report.

Column 2. Complete for each concentration ≥ 50 mg/kg

<u>Fiberglass Insulation Application Sample Description</u>	<u>Concentration (mg/kg)</u>	<u>Estimate Amount of Material</u>	<u>Units</u>
<i>Example:</i>			
<i>Fiberglass Insulation Sample 1</i>	78	86	Square Feet
1. _____	_____	_____	Square Feet
2. _____	_____	_____	Square Feet
3. _____	_____	_____	Square Feet
4. _____	_____	_____	Square Feet
5. _____	_____	_____	Square Feet
6. _____	_____	_____	Square Feet
7. _____	_____	_____	Square Feet
8. _____	_____	_____	Square Feet
9. _____	_____	_____	Square Feet
10. _____	_____	_____	Square Feet

The area of insulation wrapped around a pipe may be estimated using the following formula:
 Area (square feet) = $2\pi rh$; where r is the pipe radius (feet) and h is the pipe length (feet).

Duplicate page if additional space is needed.

Part 3 Thermal Insulation Applications Table

Column 1. Report all PCBs concentrations for each homogenous area of thermal insulation (see Attachment C, Section 3.2.2). Use sample designators/descriptions from laboratory report.

Column 2. Complete for each concentration ≥ 50 mg/kg

<u>Thermal Insulation Application Sample Description</u>	<u>Concentration (mg/kg)</u>	<u>Estimate Amount of Material</u>	<u>Units</u>
<i>Example:</i>			
<i>Thermal Insulation Sample 1</i>	20	_____	Square Feet
1. _____	_____	_____	Square Feet
2. _____	_____	_____	Square Feet
3. _____	_____	_____	Square Feet
4. _____	_____	_____	Square Feet
5. _____	_____	_____	Square Feet
6. _____	_____	_____	Square Feet
7. _____	_____	_____	Linear Feet
8. _____	_____	_____	Square Feet
9. _____	_____	_____	Square Feet
10. _____	_____	_____	Square Feet

The area of of insulation wrapped around a pipe may be estimated using the following formula:
 Area (square feet) = $2\pi rh$, where r is the pipe radius (feet) and h is the pipe length (feet).

Duplicate page if additional space is needed.

Part 3 Adhesive Mastic Applications Table

Column 1. Report PCBs concentrations for each homogenous area of mastic (see Attachment C, Section 3.2.2. Use sample designators/descriptions from laboratory report.)

Column 2. Complete for each concentration ≥ 50 mg/kg

<u>Adhesive Mastic Application Sample Description</u>	<u>Concentration (mg/kg)</u>	<u>Estimate Amount of Material</u>	<u>Units</u>
<i>Example:</i>			
<i>Adhesive Mastic Sample 1</i>	87.4	800	Square Feet
1. _____	_____	_____	Square Feet
2. _____	_____	_____	Square Feet
3. _____	_____	_____	Square Feet
4. _____	_____	_____	Square Feet
5. _____	_____	_____	Square Feet
6. _____	_____	_____	Square Feet
7. _____	_____	_____	Linear Feet
8. _____	_____	_____	Square Feet
9. _____	_____	_____	Square Feet
10. _____	_____	_____	Square Feet

Duplicate page if additional space is needed.

Part 3 Rubber Window Gasket Applications Table

Column 1. Report PCBs concentrations for each gasket (see Attachment C, Section 3.2.2). Use sample designators/descriptions from laboratory report.

Column 2. Complete for each concentration ≥ 50 mg/kg

<u>Rubber Window Gasket Application Sample Description</u>	<u>Concentration (mg/kg)</u>	<u>Estimate Amount of Material</u>	<u>Units</u>
<i>Example:</i>			
<i>Window Gasket Sample 1</i>	70	75	Linear Feet
1. _____	_____	_____	Linear Feet
2. _____	_____	_____	Linear Feet
3. _____	_____	_____	Linear Feet
4. _____	_____	_____	Linear Feet
5. _____	_____	_____	Linear Feet
6. _____	_____	_____	Linear Feet
7. _____	_____	_____	Linear Feet
8. _____	_____	_____	Linear Feet
9. _____	_____	_____	Linear Feet
10. _____	_____	_____	Linear Feet

Duplicate page if additional space is needed.

Part 3 Other Materials Table

Column 1. *Optional: Use this form to report PCBs concentration data from materials other than priority building materials. Report PCBs concentrations for each material and homogeneous area. Use sample designators/descriptions from laboratory report.*

Column 2. *Complete for each concentration ≥ 50 mg/kg*

<u>Material Sample Description</u>	<u>Concentration (mg/kg)</u>	<u>Estimate Amount of Material</u>	<u>Units</u>
<i>Example:</i>			
<i>Wall paint Sample 1</i>	<i>228</i>	<i>1500</i>	<i>Square Feet</i>
1. _____	_____	_____	_____
2. _____	_____	_____	_____
3. _____	_____	_____	_____
4. _____	_____	_____	_____
5. _____	_____	_____	_____
6. _____	_____	_____	_____
7. _____	_____	_____	_____
8. _____	_____	_____	_____
9. _____	_____	_____	_____
10. _____	_____	_____	_____


Duplicate page if additional space is needed.

Attachment C
Protocol for Evaluating Priority PCBs-Containing
Materials before Building Demolition

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition



Managing PCBs–Containing Building Materials during Demolition: Guidance, Tools, Outreach and Training



August 2018
(Revised November 2019)

This document is a deliverable of the Bay Area Stormwater Management Agencies Association (BASMAA) project *Managing PCBs–Containing Building Materials during Demolition: Guidance, Tools, Outreach and Training*. BASMAA developed guidance, tools, and outreach and training materials to assist with San Francisco Bay Area municipal agencies’ efforts to address the requirements of Provision C.12.f. of the Bay Area Municipal Regional Stormwater Permit (referred to as the MRP). Provision C.12.f of the MRP requires Permittees to manage PCBs–containing building materials during demolition.

We gratefully acknowledge the BASMAA Steering Committee for this project, which provided overall project oversight, including during the development of this and other project deliverables:


- Reid Bogert, Stormwater Program Specialist, San Mateo Countywide Water Pollution Prevention Program (BASMAA Project Manager)
- Amanda Booth, Environmental Program Analyst, City of San Pablo
- Kevin Cullen, Program Manager, Fairfield-Suisun Urban Runoff Management Program
- Matt Fabry, Program Manager, San Mateo Countywide Water Pollution Prevention Program
- Gary Faria, Supervisor, Inspection Services, Building Inspection Division, Contra Costa County
- Napp Fukuda, Deputy Director - Watershed Protection Division, City of San José
- Ryan Pursley, Chief Building Official, Building Division, City of Concord
- Pam Boyle Rodriguez, Manager, Environmental Control Programs – Stormwater, City of Palo Alto
- Jim Scanlin, Program Manager, Alameda Countywide Clean Water Program
- Melody Tovar, Regulatory Programs Division Manager, City of Sunnyvale

We also gratefully acknowledge the project Technical Advisory Group, which provided feedback from a variety of project stakeholders during development of selected project deliverables:

Stakeholder Group	Representative(s)
Regulatory – stormwater/PCBs	Luisa Valiela and Carmen Santos, U.S. EPA Region 9
Regulatory – stormwater/TMDL	Jan O’Hara, San Francisco Bay Regional Water Quality Control Board
Regulatory – experience with related program (asbestos management)	Ron Carey and Richard Lew, Bay Area Air Quality Management District
Industry – demolition contractors	Avery Brown, Ferma Corporation
Industry – remediation consultants	John Martinelli, Forensic Analytical Consulting John Trenev, Bayview Environmental Services, Inc.
MRP Permittee – large municipality	Patrick Hayes, City of Oakland
MRP Permittee – medium municipality	Kim Springer, San Mateo County Office of Sustainability
MRP Permittee – small municipality	Amanda Booth, City of San Pablo

Prepared for:

BASMAA
P.O. Box 2385
Menlo Park, CA 94026



Prepared by:

EOA, Inc.
Larry Walker Associates
Geosyntec Consultants
Stephanie Hughes
David J. Powers & Associates, Inc.



TABLE OF CONTENTS

DISCLAIMER	iv
1. INTRODUCTION	1
2. PCBS BUILDING MATERIAL EVALUATION PROTOCOL.....	3
2.1 Priority Building Materials to be Tested.....	3
2.2 PCBs Sampling Procedures	5
2.2.1 Sampling Equipment.....	5
2.2.2 Sample Collection Frequency	6
2.2.3 Sample Analysis and Preservation.....	8
2.2.4 Quality Assurance and Quality Control.....	8
2.3 Reporting and Notifications.....	9
3. REFERENCES	10

LIST OF APPENDICES

- Appendix A: PCBs Building Material Prioritization Worksheet**
- Appendix B: Priority Building Materials Photographic Log**
- Appendix C: Current Established Building Material Evaluation Protocols**
- Appendix D: Document Revision History**

DISCLAIMER

Information contained in BASMAA products is to be considered general guidance and is not to be construed as specific recommendations for specific cases. BASMAA is not responsible for the use of any such information for a specific case or for any damages, costs, liabilities or claims resulting from such use. Users of BASMAA products assume all liability directly or indirectly arising from use of the products.

The material presented in this document is intended solely for the implementation of a municipal regulatory program required by the San Francisco Bay Area Regional Water Quality Control Board Municipal Regional Stormwater Permit for the protection of water quality under the Clean Water Act.

BASMAA prepared the tools and guidance herein to assist MRP Permittees' efforts to address the requirements of Provision C.12.f. of the MRP. The project team received input from a variety of stakeholders during development of the tools and guidance, including regulators (San Francisco Bay Regional Water Quality Control Board, U.S. EPA, and Bay Area Air Quality Management District staff), Bay Area municipal agency staff, and industry representatives.

This document does not address other environmental programs or regulations (e.g., PCBs regulations under the Toxic Substances Control Act (TSCA); federal, state, or local regulations for hazardous material handling and hazardous waste disposal; health and safety practices to mitigate human exposure to PCBs or other hazardous materials; recycling mandates; and abatement at sites with PCBs (or other contaminants). The applicant is responsible for knowing and complying with all relevant laws and regulations.

The mention of commercial products, their source, or their use in connection with information in BASMAA products is not to be construed as an actual or implied approval, endorsement, recommendation, or warranty of such product or its use in connection with the information provided by BASMAA.

This disclaimer is applicable to all BASMAA products, whether information from the BASMAA products is obtained in hard copy form, electronically, or downloaded from the Internet.

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

1. INTRODUCTION

The San Francisco Bay Region Municipal Regional Stormwater NPDES permit, referred to as the Municipal Regional Permit (MRP)¹, includes provisions that implement stormwater-related aspects of the Total Maximum Daily Load (TMDL) for polychlorinated biphenyls (PCBs) in the Bay. Provision C.12.f. requires that Permittees develop and implement or cause to be developed and implemented an effective protocol for managing materials with PCBs concentrations of 50 milligrams per kilogram (mg/kg) (equivalent to parts-per-million, or ppm), the target management level, or greater in applicable structures at the time such structures undergo demolition², so that PCBs do not enter municipal storm drain systems. Applicable structures include, at a minimum, non-residential structures constructed or remodeled between the years 1950 and 1980 with building materials such as caulking and thermal insulation with PCBs concentrations of 50 ppm or greater. Single-family residential and wood frame structures are exempt. Also, a Permittee is exempt from this requirement if it provided evidence acceptable to the Executive Officer in its 2016/17 Annual Report that the only structures that existed pre-1980 within its jurisdiction were single-family residential and/or wood-frame structures.³

Permittees were required to develop a protocol by June 30, 2019 that includes each of the following components, at a minimum:

1. The necessary authority to ensure that PCBs do not enter municipal storm drains from PCBs-containing materials in applicable structures at the time such structures undergo demolition;
2. A method for identifying applicable structures prior to their demolition; and
3. Method(s) for ensuring PCBs are not discharged to the municipal storm drain from demolition of applicable structures.

By July 1, 2019 and thereafter, Permittees are required to:

- Implement or cause to be implemented the PCBs management protocol for ensuring PCBs are not discharged to municipal storm drains from demolition of applicable structures via vehicle track-out, airborne releases, soil erosion, or stormwater runoff.
- Develop an evaluation methodology and data collection program to quantify in a technically sound manner PCBs loads reduced through implementation of the protocol for controlling PCBs during demolition of applicable structures.

On behalf of MRP Permittees, the Bay Area Stormwater Management Agencies Association (BASMAA) conducted a regional project to assist MRP Permittees to achieve compliance with

¹ The Municipal Regional Stormwater Permit, Order No. R2-2015-0049, was adopted November 19, 2015.

² Demolition means the wrecking or taking out of any load-supporting structural member of a facility together with any related handling operations (40 CFR., Part 61, Subpart M).

³ The City of Clayton provided evidence to support an exemption from the requirement.

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

Provision C.12.f. The regional project developed guidance materials, tools, protocols and training materials and conducted outreach. The goal was to assist Permittees to develop local programs to prevent PCBs from being discharged to municipal storm drains due to demolition of applicable buildings. Local agencies will need to tailor the BASMAA products for local use and train local staff to implement the new program.

This document is the deliverable for Task 3 of the regional project, which is to develop a protocol for the assessment of prioritized PCBs-containing building materials prior to demolition. The full scope of work for the regional project is presented in the Project team's *Proposal for Tools, Protocol, Outreach & Training Work Plan: PCBs Materials Management during Building Demolition Project* (dated January 31, 2017; revised March 2017). If materials are found or known to contain PCBs, those materials must be managed appropriately and according to all applicable local, state, and federal requirements. Guidance on the management of PCBs-containing materials is beyond the scope of this document.

To establish the PCBs protocol, currently established protocols were evaluated that are widely accepted in the building demolition industry for other Federal- and State-regulated constituents of concern. This document provides applicable examples of sampling and evaluation procedures for building materials potentially contaminated with asbestos-containing material (ACM)⁴ and lead-based paint (LBP)⁵, which are summarized and referenced in Appendix C. These components include guidance on sampling frequencies, laboratory sample analysis, quality assurance and quality control procedures, and reporting.

⁴ Asbestos-containing material (ACM) means any material or product which contains more than one percent asbestos.

⁵ Lead-based paint (LBP) is any paint, varnish, shellac, or other coating that contains lead equal to or greater than 1.0 mg/cm² as measured by XRF device or laboratory analysis, or 0.5 percent by weight (5,000 ppm or 5,000 mg/kg) as measured by laboratory analysis.

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

2. PCBs BUILDING MATERIAL EVALUATION PROTOCOL

This section presents the evaluation protocol for identifying building materials in structures constructed or remodeled between the years 1950 and 1980⁶ that may contain a significant mass of PCBs. Once identified as containing PCBs at concentrations exceeding 50 ppm, these materials should be properly managed prior to building demolition, to ensure PCBs are not discharged to the municipal storm drain system.

This protocol is not intended to address all PCBs-containing materials that may be disturbed during building demolition. Additional sampling is likely to be required to comply with USEPA and Cal/OSHA regulations pertaining to the management, removal and disposal of PCBs-containing materials.

For this program, it is assumed that organizations and staff qualified to sample, test, remediate, and dispose of PCBs at the building site will coordinate processes for other hazardous building materials at the building site, to ensure proper sampling, testing, remediation, and disposal or all statutorily required hazardous materials handling.

2.1 Priority Building Materials to be Tested

A prioritized list of PCBs-containing materials is provided in Appendix A. Building materials were evaluated based upon the following criteria:

- **Source Material** – Does the building material contain PCBs through the original product manufacturing process or was the building material contaminated (impregnated) with PCBs from an adjacent building material that already contained PCBs? For the evaluation, building materials originally manufactured with PCBs at or above 50 mg/kg were prioritized.
- **Concentration** – Building materials were evaluated based on readily available existing data regarding ranges of PCBs concentrations identified in the materials.
- **Prevalence** – A prevalence factor was assigned based upon best professional judgement of the prevalence of occurrence of the PCBs-containing materials in buildings, which ranged from highly prevalent to low prevalence.
- **Ease of Removal** – Building materials were evaluated based on their attachment to the building, which ranged from “very easily removed” to “difficult to remove,” under the assumption that higher ease of removal results in higher feasibility and lower costs for removing a material before demolition.

⁶ Single-family residential and wood frame structures are exempt.

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

- **Flaking/Crumbling** – Building materials were evaluated based on their tendency to flake or crumble during disturbance or demolition, which could lead to a higher likelihood of entering stormwater as a result of building demolition.
- **PCBs Removed by Other Waste Program** – This factor addresses materials that are removed from buildings because of other waste management programs (e.g., Universal Waste Rule). Fluorescent light ballasts⁷, polyurethane foam furniture, and Askarel fluid used in transformers, all of which may contain PCBs, are typically managed during pre-demolition activities under current regulations and programs that require removal of universal waste and outdated transformers. For this program it is assumed that those materials will be evaluated and managed under those existing programs.

Material prioritization was conducted by assigning a score on a scale of 1 to 5 (low to high) for each criterion. The final score for each material type was calculated as the average of the scores assigned to the six criteria. The materials given the highest scores through the prioritization analysis are shown below, along with their typical locations in a building. For this evaluation, thermal insulation and fiberglass insulation were grouped together as they tend to be co-located and are typically managed together.

Many building materials may contain PCBs. The building owner is responsible for identifying and handling all hazardous materials in accordance with all applicable laws, including all materials with 50 ppm or more PCBs. For purposes of obtaining a demolition permit, the building owner must sample at least the limited number of priority building materials listed below⁸ (along with typical locations where they are found) using the protocols described in Section 2.2. This protocol is only for sampling of priority building materials. Building materials coming into contact with priority building materials are not the focus of this protocol.

1. Caulks and Sealants:

- a. Around windows or window frames (e.g., window glazing putty, window caulking, etc.);
- b. Around door frames; and
- c. Expansion joints between concrete sections (e.g., floor segments).

2. Thermal/Fiberglass Insulation and Other Insulating Materials:

- a. Around HVAC systems,

⁷ Fluorescent light ballasts that contain PCBs are not required to be managed under the Universal Waste Rule Program but are recommended by the EPA to be identified in a pre-demolition survey of a structure and to be managed with the removal of other required wastes in the abatement process.

⁸ Applicants may use existing sampling results of the priority building materials. Applicants who have conducted sampling prior to the publication of this protocol may use that data provided it is consistent with this protocol (e.g., analytical methods, sample collection frequency, and QA/QC).

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

- b. Around heaters,
 - c. Around boilers,
 - d. Around heated transfer piping, and
 - e. Inside walls or crawls spaces.
3. Adhesive/Mastic:
 - a. Below carpet and floor tiles;
 - b. On, under, or between roofing materials and flashing.
 4. Rubber Window Seals/Gaskets:
 - a. Around windows or window frames.

Examples of the prioritized PCBs-containing building materials and what they may look like in a building planned for demolition are provided in Appendix B.

It should be noted that some materials that are being evaluated for PCBs in this protocol may also be associated with asbestos, lead, or other hazardous substances. Since this protocol follows pre-established asbestos management program guidelines and procedures, the sampling frequency, types of building materials, and surveying techniques overlap with the PCBs survey protocol. If a material has been determined to contain asbestos, lead or other hazardous substances and will be abated under an associated waste program, that material need not be sampled for PCBs under this program.

2.2 PCBs Sampling Procedures

2.2.1 Sampling Equipment

Building materials that are planned to be collected for laboratory analysis should be placed in laboratory-supplied glass jars with Teflon-sealed lids following procedures established in USEPA Method 8082 / 8082A. Samples should be collected with either factory-sealed or decontaminated equipment that will be used to remove a representative building material sample (i.e., scissors, tweezers, pliers, spoons, or putty knife).

For sampling equipment (i.e., scissors, tweezers, pliers, spoons, putty knife, etc.) that will be decontaminated, the following three bucket wash procedure should be performed, which is in general accordance with standard decontamination procedures defined in SESDPROC-205-R3 (USEPA, 2015):

- In the first bucket, mix a residue free cleaning detergent (e.g., Alconox®), with distilled water to generate the recommended detergent concentration specified in the product directions;

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

- Fill the second bucket with distilled water;
- Fill the third bucket with distilled water;
- Clean the equipment in the first bucket with the cleaning detergent, then rinse in the second and then the third bucket. If the second bucket becomes slightly discolored during the rinse, change the contents of the second bucket with distilled water. Change the third bucket, if any dirt or material is observed in the water, since the third bucket needs to stay clean as it is the final rinse; and
- At the end of cleaning, let the equipment air dry in a clean area before use in sample collection. The rinse water should then be drummed and sampled for disposal. The planned disposal facility should be contacted to determine the required sample analysis for the rinse water characterization and profiling and that the disposal procedures comply with state and federal regulations.

If disposable sampling tools are used, the above decontamination procedures do not apply. Additionally, decon with certain solvents (e.g., hexane) may be utilized for cleaning of tar-like substances, followed with the standard decontamination procedures listed above. It is recommended that equipment is air-dried per the procedure above, but it is up to the discretion of the environmental professional to use alternative drying methods if time constraints for air-drying is prohibitive.

2.2.2 Sample Collection Frequency

For the four prioritized building materials, the following collection techniques and frequency should be followed.

Caulking

Three different types of caulking should be evaluated:

1. Window caulking;
2. Door frame caulking; and
3. Floor and expansion joint caulking.

For each type of caulking material identified, the following number of samples should be collected:

- Collect at least one sample from each homogenous area that contains less than 50 linear feet of caulking;
- Collect at least three samples from each homogenous area that contains between 50 and 250 linear feet of caulking;
- Collect at least five samples from each homogenous area that contains between 250 and 1,000 linear feet of caulking;

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

- Collect at least seven samples from each homogenous area that contains between 1,000 and 2,500 linear feet of caulking; and
- Collect at least nine samples from each homogenous area that contains greater than 2,500 linear feet of caulking.

If homogenous caulking material is found throughout the building, samples should be spatially distributed so as to not collect the required number of samples from one area. In addition, the width or cross-sectional area of the caulking bead is not relevant for determining the linear footage to be sampled. It is also recommended that the sampler performing the evaluation inspect the entire building prior to sample collection to insure proper distribution is performed.

Thermal/Fiberglass Insulation

For thermal/fiberglass insulation:

- Collect at least one bulk sample from each homogeneous area.

Adhesive/Mastic

For each type of adhesive/mastic material identified, the following number of samples should be collected:

- Collect at least three samples from each homogenous area less than 1,000 square feet;
- Collect at least five samples from each homogenous area between 1,000 and 5,000 square feet; and
- Collect at least seven samples from each homogenous area greater than 5,000 square feet.

If homogenous adhesive/mastic material is found throughout the building, samples should be spatially distributed so as to not collect the required number of samples from one area. It is recommended that the sampler performing the evaluation inspect the entire building prior to sample collection to insure proper distribution is performed.

Rubber Window Seals/Gaskets

For rubber window seals/gaskets identified, the following number of samples should be collected:

- Collect at least one sample from each homogenous area that contains less than 50 linear feet of caulking (of any width or cross-sectional are of bead);
- Collect at least three samples from each homogenous area that contains between 50 and 250 linear feet of caulking;
- Collect at least five samples from each homogenous area that contains between 250 and 1,000 linear feet of caulking;

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

- Collect at least seven samples from each homogenous area that contains between 1,000 and 2,500 linear feet of caulking; and
- Collect at least nine samples from each homogenous area that contains greater than 2,500 linear feet of caulking.

If homogenous rubber window seals/gaskets are found throughout the building, samples should be spatially distributed so as to not collect the required number of samples from one area. It is also recommended that the sampler performing the evaluation inspect the entire building prior to sample collection to insure proper distribution is performed.

2.2.3 Sample Analysis and Preservation

Samples collected to evaluate building materials for PCBs should be analyzed for Aroclors by EPA Method 8082/8082A⁹ by an accredited analytical laboratory. The reporting limit goal should be 500 micrograms per kilogram ($\mu\text{g}/\text{kg}$).¹⁰ The laboratory should be contacted before sampling to confirm that it can meet the reporting limit objectives.

Samples should be chilled and then kept cool between 0 and 6 degrees Celsius (32 and 42.8 degrees Fahrenheit) during storage and transportation to the laboratory following procedures established in USEPA Method 8082/8082A. Proper chain-of-custody¹¹ procedures should be followed from the time the samples are collected until they are delivered to the laboratory for analysis. Holding times for EPA Method 8082/8082A are sample extraction within 14 days of sample collection and analysis of the extract within 40 days of extraction. However, PCBs are very stable in a variety of matrices and holding times may be extended to as long as one year. Once extracted, analysis of the extract should take place within 40 days.

2.2.4 Quality Assurance and Quality Control

For this program, general quality assurance and quality control (QA/QC) procedures will be utilized. The following checklist should be used by the contractor performing the evaluation:

- QA/QC Checklist:
 - Proper specified sampling equipment was used (pre-cleaned or other, stainless steel);

⁹ Provision C.12.f. requires that Permittees develop and implement or cause to be developed and implemented an effective protocol for managing materials with PCBs concentrations of 50 ppm. EPA Method 8082/8082A is an acceptable method to quantify PCBs. Analysis of PCBs congeners is not required to meet the permit requirement.

¹⁰ The reporting limit can be modified to account for necessary dilutions or interferences, as determined by the laboratory. This reporting limit, which is below the target management level of 50 mg/kg, was selected to allow for data to be collected on the concentration of PCBs in building materials.

¹¹ Chain-of-custody is the procedure to document, label, store, and transfer samples to personnel and laboratories. For a detailed list of procedures, refer to the *Sample and Evidence Management, Operating Procedure* (SESDFPROC-005-R2), January 29, 2013

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

- Proper decontamination procedures were followed;
- Sampling collection spatial frequency was met;
- A National Environmental Laboratory Accreditation Program (NELAP) laboratory or a California-ELAP (CA-ELAP) were utilized;
- Samples were received by the laboratory within proper temperature range;
- Samples were extracted and analyzed within the method holding time for EPA Method 8082/8082A; and
- Sample reporting limit met data quality objectives.

2.3 Reporting and Notifications

The following considerations are applicable to reporting and notification:

- Assessment results must be submitted to the applicable Permitting Authority by the project applicant;
- Applicants that determine PCBs exist in priority building materials must follow applicable federal and state laws. This may include reporting to USEPA, the San Francisco Bay Regional Water Quality Control Board, and the California Department of Toxic Substances Control (DTSC). These agencies may require additional sampling and abatement of PCBs.
- Depending on the approach for sampling and removing building materials containing PCBs, applicants may need to notify or seek advance approval from USEPA before building demolition. Even in circumstances where advance notification to or approval from USEPA is not required before the demolition activity, the disposal of PCBs waste is regulated under TSCA.
- The disposal of PCBs waste is subject to California Code of Regulations (CCR) Title 22, Section Division 4.5, Chapter 12, Standards Applicable to Hazardous Waste Generators.
- Building owners and employers need to consider worker and public safety during work involving hazardous materials and wastes including PCBs.

For further information, applicants should refer to the *PCBs in Priority Building Materials Screening Assessment Applicant Package*, BASMAA, July 2018.

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

3. REFERENCES

Guidelines for Asbestos Sampling:

- <https://www.epa.gov/asbestos/asbestos-laws-and-regulations>

Guidelines for Lead-Based Paint Evaluations:

- Environmental Protection Agency (EPA) - Created the Renovation, Repair, and Painting (RRP) Rule which requires training and certification for anyone working for compensation in pre-1978 residential structures, day care centers, and schools where known or assumed lead-based paint is impacted. The EPA website with complete information on this regulation is <https://www.epa.gov/lead/renovation-repair-and-painting-program>.
- California Department of Public Health (CDPH) - Created "Title 17" which includes lead testing and abatement provisions in residential and public structures in California. Several important definitions are contained in Title 17 including Abatement, Clearance Inspection, Containment, Lead-Based Paint.
- Lead Contaminated Dust and Soil, Lead Hazard, and Lead Hazard Evaluation. Title 17 establishes that lead testing be performed using XRF equipment or by paint chip sample analysis in California. Lead test kits are not accepted. It also establishes testing in California be performed by a State certified lead inspector/assessor if the testing is related to a project involving compensation.
- Department of Housing and Urban Development (HUD) - Created the HUD Guidelines which contain protocols for lead testing and abatement.

EPA Method 8082A – Polychlorinated Biphenyls (PCBs) by Gas Chromatography

- <https://www.epa.gov/sites/production/files/2015-07/documents/8082a.pdf>

SESDPROC-205-R3, *Field Equipment Cleaning and Decontamination*, replaces SESDPROC-205-R2. December 18, 2015

- https://www.epa.gov/sites/production/files/2016-01/documents/field_equipment_cleaning_and_decontamination205_af.r3.pdf

SESDPROC-005-R2, *Sample and Evidence Management*, Operating Procedure, January 29, 2013

- <https://www.epa.gov/sites/production/files/2015-06/documents/Sample-and-Evidence-Management.pdf>

APPENDIX A

PCBs Building Material Prioritization Worksheet

Appendix A - PCBs Building Materials Prioritization

Material	Material Class	Median/Average/Single Reported Concentration (ppm)	Minimum (ppm)	Maximum (ppm)	PCBs Source Material? (Rating values: source = 5, or not source = 1)	Concentration (Rating values: 1 to 5, higher value means higher concentration)	Prevalence of PCBs Containing Material in Buildings (Rating values: high = 5, medium = 3, or low = 1)	Ease of Removal (Rating values: 1 to 5, higher value means easier to remove)	Flaking/ Crumbling (Rating values: 1 to 5, higher value means more likely to flake/crumble)	PCBs Removed by Other Waste Program? (Rating values: not removed by other = 5, or removed = 1)	Prioritization Score
Caulking (sealant, plaster)	Caulk/sealant/tape/glue		0.001	752,000	5	5	5	3	5	5	4.67
Thermal insulation	Insulation			73,000	5	5	5	4	4	5	4.67
Fiberglass insulation	Insulation			39,158	5	4	5	4	4	5	4.50
Adhesives/mastic	Caulk/sealant/tape/glue			3,100	5	3	5	3	5	5	4.33
Rubber gaskets	Gaskets/Rubber			84,000	5	5	3	3	4	5	4.17
Wool felt gaskets	Gaskets/Rubber			688,498	5	5	3	3	4	5	4.17
Cloth/paper insulating material	Insulation			12,000	5	4	3	4	4	5	4.17
Foam rubber insulation	Insulation			13,100	5	4	3	4	4	5	4.17
Ceiling tiles coated w/ flame resistant sealant	Internal nonstructural surface		53	110,000	5	5	5	3	2	5	4.17
Backer rod	Caulk/sealant/tape/glue			99,000	1	5	5	3	5	5	4.00
Roofing/siding material	External nonstructural surface		0	30,000	5	4	5	3	2	5	4.00
Paint (complete removal)	Paint/pigment/coatings		0.001	97,000	5	5	5	1	3	5	4.00
Insulating materials in electric cable	Electrical		0	280,000	5	5	3	4	1	5	3.83
Adhesive tape	Caulk/sealant/tape/glue			1,400	5	3	1	3	5	5	3.67
Surface coating	Paint/pigment/coatings			255	5	3	5	1	3	5	3.67
Coal-tar enamel coatings	Paint/pigment/coatings			1,264	5	3	5	1	3	5	3.67
Grout	Caulk/sealant/tape/glue			9,100	5	4	1	2	5	5	3.67
Cove base	Internal nonstructural surface			170	5	3	3	4	2	5	3.67
Plastics/plasticizers	Electrical			13,000	5	4	3	3	1	5	3.50
GE silicones	Caulk/sealant/tape/glue	<1.9	0	1.8	5	1	3	2	5	5	3.50
Glazing	Caulk/sealant/tape/glue	Up to 100% liquid PCBs		51	5	2	3	3	3	5	3.50
Flooring and floor wax/sealant	Internal nonstructural surface	Maximum likely >50		51	5	2	3	3	2	5	3.33
Light ballast	Light ballasts	Minimum likely <50	49	1,200,000	5	5	3	5	1	1	3.33
Anti-fouling compounds	Paint/pigment/coatings			59,000	5	4	1	1	3	5	3.17
Polyurethane foam (furniture)	Caulk/sealant/tape/glue			50	5	2	1	5	5	1	3.17
Askarel fluid/cutting oils/hydraulic fluid	Oils/dielectric fluids			450,000	5	5	1	5	2	1	3.17
Fire retardant coatings	Paint/pigment/coatings			59,000	5	4	1	1	3	5	3.17
Waterproofing compounds	Paint/pigment/coatings			59,000	5	4	1	1	3	5	3.17
Electrical wiring	Electrical			14	5	1	3	4	1	5	3.17
Concrete	Concrete/stone	2.5	0.001	17,000	1	4	3	1	4	5	3.00
Foam rubber	Gaskets/Rubber			1,092	1	3	1	3	4	5	2.83
Soil/sediment/sand	Soil/dust	0.15	0.001	581	1	3	1	2	5	5	2.83
Brick/mortar/cinder block	Concrete/stone			1,100	1	3	3	1	4	5	2.83
Wood	Wood			380	1	3	3	3	2	5	2.83
Door frame	Internal nonstructural surface			102	1	2	3	4	2	5	2.83
Metals surfaces in contact with caulk/sealant	Metal surfaces	448	51	448	1	3	1	2	4	5	2.67

Appendix A - PCBs Building Materials Prioritization

Material	Material Class	Median/Average/Single Reported Concentration (ppm)	Minimum (ppm)	Maximum (ppm)	PCBs Source Material? (Rating values: source = 5, or not source = 1)	Concentration (Rating values: 1 to 5, higher value means higher concentration)	Prevalence of PCBs Containing Material in Buildings (Rating values: high = 5, medium = 3, or low = 1)	Ease of Removal (Rating values: 1 to 5, higher value means easier to remove)	Flaking/ Crumbling (Rating values: 1 to 5, higher value means more likely to flake/crumble)	PCBs Removed by Other Waste Program? (Rating values: not removed by other = 5, or removed = 1)	Prioritization Score
Asphalt	Concrete/stone			140	1	2	1	2	4	5	2.50
Carpet	Internal nonstructural surface		0.46	9.7	1	1	1	5	2	5	2.50
Stone (granite, limestone, marble, etc.)	Concrete/stone			130	1	2	1	1	4	5	2.33
Air handling system	Air system		0.46	9.7	1	1	1	3	1	5	2.00

APPENDIX B

Priority Building Materials

Photographic Log

Appendix B

Priority Building Materials to be Tested for PCBs

Photograph 1

Window Caulking:

Damaged caulking around a window.



Photograph 2

Window Caulking:

Worn and cracked caulking around a window.



Appendix B

Priority Building Materials to be Tested for PCBs

Photograph 3

Door Frame Caulking:

Caulking on an interior door or window frame.



Photograph 4

Floor and Expansion Joint Caulking:

Caulking material placed in concrete expansion joints.



Appendix B

Priority Building Materials to be Tested for PCBs

Photograph 5

Thermal Insulation:

Foam-style thermal insulation material along wall.



Photograph 6

Thermal Insulation:

Damaged floor foam insulation.



Appendix B

Priority Building Materials to be Tested for PCBs

Photograph 7

Thermal Insulation:

Damaged felt-style thermal insulation.



Photograph 8

Thermal Insulation:

Exposed/damaged fiberglass insulation.



Appendix B

Priority Building Materials to be Tested for PCBs

Photograph 9

Thermal Insulation:

Exposed and damaged pipe insulation.



Photograph 10

Thermal Insulation:

Pipe insulation.




Appendix B

Priority Building Materials to be Tested for PCBs

Photograph 11

Adhesive / Mastic:

Adhesive/mastic on a roof surface.



Photograph 12

Adhesive / Mastic:

Adhesive beneath a carpet.



Appendix B

Priority Building Materials to be Tested for PCBs

Photograph 13

Adhesive / Mastic:

Adhesive remnants on flooring.



Photograph 14

Adhesive / Mastic:

Exposed adhesive on roofing.



Appendix B

Priority Building Materials to be Tested for PCBs

Photograph 15

Rubber Window Seal/Gasket:

Grey rubber window seal/gasket in a wood type frame.



Photograph 16

Rubber Window Seal/Gasket:

Off white rubber window seal/gasket in an aluminum type frame.



APPENDIX C

Currently Established Building Material Evaluation Protocols

1. CURRENTLY ESTABLISHED BUILDING MATERIAL EVALUATION PROTOCOLS

This section presents evaluation protocols for ACM and LBP, which provide a foundation for the PCBs protocol summarized in Section 3. This section includes guidance on sampling frequencies, laboratory sample analysis, quality assurance and quality control procedures derived from regulatory procedures for ACM and LBP.

1.1 Asbestos Containing Material Evaluation Procedures

Asbestos bulk sampling procedures are specified in several Federal regulations, implemented primarily by the United States Environmental Protection Agency (EPA) as well as the Occupational Safety and Health Administration (OSHA). The Consumer Product Safety Commission (CPSC) and the Mine Safety and Health Administration (MSHA) specify additional regulations and procedures, but these are generally less applicable to evaluation procedures.

The foundational regulations pertaining to asbestos sampling in buildings are the Asbestos Hazard Emergency Response Act (AHERA; Toxic Substances Control Act [TSCA] Title II) (15 U.S.C. § 2641-2656) as well as the Asbestos School Hazard Abatement Reauthorization Act (ASHARA). EPA promulgated regulations under AHERA to require inspection of schools for asbestos-containing building materials, and to perform resultant corrective actions. Furthermore, AHERA tasked the EPA with developing a plan for accreditation of asbestos inspectors. ASHARA extended funding for asbestos programs at schools and expanded accreditation requirements to cover asbestos abatement at commercial buildings other than schools.

Pursuant to AHERA, the Asbestos-Containing Materials in Schools rule (40 CFR Part 763, Subpart E) details specific requirements for building material inspections at schools, preparation of asbestos management plans, and implementation of response actions. EPA regulation on asbestos related to structure demolition is specified in subpart M of the National Emission Standards for Hazardous Air Pollutants (NESHAP) regulations (40 CFR Part 61, Subpart M).

The following sections summarize the evaluation procedures specified in the Asbestos-Containing Materials in Schools rule as well as the Asbestos NESHAP regulations. Both OSHA and EPA worker protection requirements are also discussed.

1.1.1 Asbestos-Containing Materials in Schools Rule

The following sections summarize the inspection, re-inspection, sampling, analysis, and evaluation procedures specified in the Asbestos-Containing Materials in Schools rule (40 CFR Part 763, Subpart E).

Evaluation

For each inspection and re-inspection of asbestos-containing building material (ACBM)¹², the local education agency shall have an accredited inspector provide a written evaluation of all friable known or assumed ACBM. The evaluation shall consider the following:

- Location and amount of material, both in total quantity and as a percentage of the functional space;
- Condition of the material, specifying:
 - Type of damage or significant damage (e.g., flaking, blistering, water damage, or other signs of physical damage);
 - Severity of damage (e.g., major flaking, severely torn protective jackets, as opposed to occasional flaking, minor tears to jackets);
 - Extent or spread of damage over large areas or large percentages of the homogeneous¹³ area;
- Whether the material is accessible;
- The material's potential for disturbance;
- Known or suspected causes of damage or significant damage (e.g., air erosion, vandalism, vibration, water); and
- Preventive measures that could potentially eliminate the reasonable likelihood of undamaged ACBM from becoming significantly damaged.

The inspector shall classify and give reasons in the written evaluation for classifying the ACBM and suspected ACBM assumed to be ACM into one of the following categories:

¹² Asbestos-containing building material (ACBM) means surfacing ACM, thermal system insulation ACM, or miscellaneous ACM that is found in or on interior structural members or other parts of a building.

¹³ Homogenous refers to a substance or area that is uniform in texture, color, and general physical appearance and properties.

1. Damaged or significantly damaged thermal system insulation ACM;
2. Damaged friable surfacing ACM;
3. Significantly damaged friable surfacing ACM;
4. Damaged or significantly damaged friable miscellaneous ACM;
5. ACBM with potential for damage;
6. ACBM with potential for significant damage; and
7. Any remaining friable ACBM or friable suspected ACBM.

Inspection and Re-inspection

Inspect any building that is to be used as a school, prior to such use, by an accredited inspector. In emergency situations, inspect the building within 30 days of commencement of such use.

For each area of the building, complete the following inspection procedure:

- Visually inspect the area to identify suspected ACBM;
- Touch suspected ACBM to determine friability (Friable material is material that may be crumbled or pulverized by hand pressure alone. Note that thermal system insulation that has retained its structural integrity and that has an undamaged protective jacket or wrap that prevents fiber release shall be treated as non-friable.);
- Categorize all areas into homogenous areas of friable suspected ACBM and non-friable suspected ACBM;
- Assume that some or all the homogeneous areas are ACBM, and for each homogeneous area that is not assumed to be ACBM, collect and submit samples for bulk analysis. Do not sample areas that an accredited inspector assumes to contain ACBM. For uncertain areas, collect and bulk samples and submit for analysis (see Sampling below);
- Assess friable material in areas where samples are collected, in areas where samples are not collected but ACBM is assumed to be present, and in areas identified in previous inspections;
- Record the following information and submit a copy for inclusion in an asbestos management plan, within 30 days of the inspection:

- An inspection report including the signature, state of accreditation, and accreditation number of each inspector, as well as the date of the inspection;
- A comprehensive inspection inventory, including the date and locations of samples, locations of areas assumed to contain friable ACBM, and locations of areas assumed to contain non-friable ACBM;
- A description of the manner used to determine sampling locations;
- A list of all categorized and identified homogenous areas into surfacing material, thermal system insulation, or miscellaneous material; and
- Evaluations made of friable material.

Repeat this process as a re-inspection at least once every 3 years after a management plan is in effect. Reassess the condition of friable known or assumed ACBM previously identified. Identify any homogenous areas with material that has become friable since the last inspection or re-inspection and collect and submit samples of the material.

Sampling

Collect samples in a statistically random manner that is representative of each homogeneous area.

- For surfacing material, the number of samples to be collected is as follows:
 - Collect at least three samples from each homogenous area less than 1,000 square feet;
 - Collect at least five samples from each homogenous area between 1,000 and 5,000 square feet; and
 - Collect at least seven samples from each homogenous area greater than 5,000 square feet.
- For thermal system insulation:
 - Collect at least one bulk sample from each homogeneous area that is not assumed to be ACM;
 - Collect at least one bulk sample from each homogeneous area of patched insulation that is not assumed to be ACM, if the patched section is less than six linear or square feet;

- Where cement or plaster is used on fittings such as tees, elbows or valves, collect samples to determine if material is ACM or not;
- If the accredited inspector determines that the thermal system insulation is fiberglass, foam glass, rubber, or other non-ACBM, samples are not required to be collected;
- For miscellaneous material, collect bulk samples from each homogeneous area of friable material that is not assumed to be ACM.

Analysis

Samples should be analyzed by laboratories accredited by the National Bureau of Standards (NBS). The laboratories must have received interim accreditation for polarized light microscopy (PLM) analysis under the EPA Interim Asbestos Bulk Sample Analysis Quality Assurance Program until the NBS PLM laboratory accreditation program for PLM is operational.

Samples should be analyzed for asbestos content by PLM using the “Interim Method for the Bulk Determination of Asbestos in Bulk Insulation Samples”, found at Appendix E to Subpart E of 40 CFR Part 763. Samples should not be composited.

A homogenous area is considered not to contain ACM only if the results of all samples from that area show asbestos in concentrations of 1 percent or less. An area is considered to contain ACM if at least one sample from the area shows asbestos in concentrations greater than 1 percent.

Submit the name and address of each laboratory performing the analysis, the date of the analysis, and the person performing the analysis for inclusion into the management plan within 30 days of the analysis.

1.2 Lead-Based Paint (LBP) Evaluation Procedures

Lead-Based Paint (LBP) evaluation procedures are codified in various federal and state regulations.

Title IV of the Toxic Substances Control Act (TSCA) as well as other authorities in the Residential Lead-Based Paint Hazard Reduction Act of 1992 directs the EPA to regulate lead-based paint hazards. The primary Federal regulations and guidelines related to LBP evaluation procedures include:

- The Lead Renovation, Repair and Painting Program (RRP) Rule (40 CFR 745, Subpart E);
- The National Lead Laboratory Accreditation Program (TSCA Section 405(b)); and
- The Housing and Urban Development (HUD) Guidelines for the Evaluation and Control of Lead-Based Paint Hazards in Housing (2012 Edition) (pursuant to Section 1017 of the Residential Lead-Based Paint Hazard Reduction Act of 1992, A.K.A. “Title X”)

Furthermore, the California Department of Public Health (CDPH) Title 17, California Code of Regulations, Division 1, Chapter 8 “Accreditation, Certification, and Work Practices for Lead-Based Paint and Lead Hazards,” specifies some LBP evaluation procedures as part of the accreditation program.

The HUD Guidelines provide the most comprehensive procedures for LBP evaluations and are referenced by many other regulations.

There are three primary methods of performing LBP evaluation: test kits, X-ray Fluorescence (XRF) devices, and laboratory testing of paint chips. Sampling procedures for each method are detailed in the following sections.

Under CDPH Title 17, certified Lead Inspector/Assessors are required to use XRF devices or laboratory analysis, and not test kits.

1.2.1 LBP Sampling Procedures: Test Kits

In 2008, the EPA published the RRP rule, which, among other things, established criteria for lead test kits for use in LBP evaluation. Lead test kits recognized by EPA before September 1, 2010, must meet only the negative response criterion outlined in 40 CFR 745.88(c)(1):

For paint containing lead at or above the regulated level, 1.0 mg/cm² or 0.5% by weight, a demonstrated probability (with 95% confidence) of a negative response less than or equal to 5% of the time must be met.

Lead test kits recognized after September 1, 2010, must meet both the negative response and positive response criteria outlined in 40 CFR 745.88(c)(1) and (2). The positive-response criterion states:

For paint containing lead below the regulated level, 1.0 mg/cm² or 0.5% by weight, a demonstrated probability (with 95% confidence) of a positive response less than or equal to 10% of the time must be met.

To date, no lead test kit has met both criteria¹⁴. However, three lead test kits recognized before September 1, 2010, exist and are recognized by EPA:

- 3M™ LeadCheck™, manufactured by the 3M Company, for use on wood, ferrous metal, drywall, and plaster surfaces;
- D-Lead®, manufactured by ESCA Tech, Inc., for use on wood, ferrous metal, drywall, and plaster surfaces; and
- The Commonwealth of Massachusetts lead test kit, for use only on drywall and plaster surfaces.

Test kits cannot determine the concentration of lead, only presence or absence at best. For this reason, test kits are best used by homeowners or other non-professionals as a preliminary evaluation before using an XRF device or laboratory analysis of paint chips.

In California, test kits are not utilized as XRF is shown to be more reliable for testing of lead concentrations in paint.

There are currently no detailed sampling procedures for test kits that would be applicable to PCBs evaluation. However, test kit technology may be a useful paradigm for PCBs evaluation if a kit can be developed to test PCBs at an acceptable concentration that uses a repeatable methodology to meet the data quality objectives.

1.2.2 LBP Sampling Procedures: XRF Devices

The following sections summarize LBP evaluation procedures for XRF devices, including description of sampling equipment, collection techniques and frequency, sample analysis, and quality assurance.

LBP Analyzers

According to the HUD Guidelines, portable XRF devices are the most common primary analytical method for inspections in housing because of their versatility in analyzing a

¹⁴ US EPA, Lead Test Kits, <https://www.epa.gov/lead/lead-test-kits>, accessed September 19, 2017.

wide variety of surface types, non-destructive measurement, high speed, and low cost per sample. Each XRF device must have a HUD-issued XRF Performance Characteristic Sheet (PCS), which contains information about XRF readings taken on specific surface types, calibration check tolerances, and interpretation of XRF readings.

Collection Techniques and Frequency

HUD Guidelines provide separate sampling techniques for single- and multi-family housing. However, the general approach to sampling is the following seven-step procedure:

- List all testing combinations of building components and substrates (e.g., wood doors, metal doors, plaster walls, concrete walls);
- Select testing combinations. A numbering system, floor plan, sketch or other system may be used to document which testing combinations were tested;
- Perform XRF testing, including calibration;
- Collect and analyze paint-chip samples as needed;
- Classify XRF and paint-chip results;
- Evaluate the work and results to ensure the quality of the inspection; and
- Document the findings in a summary and in a complete technical report.

Because of the large surfaces and quantities of paint involved, and the potential for spatial variation, HUD Guidelines recommend taking at least four readings per room, with special attention paid to surfaces that clearly have different painting history. The selection of test locations should be representative of locations most likely to be coated with old paint or other lead-based coatings, such as areas with thick paint; areas with worn or scraped off paint should be avoided.

For large buildings with many similar units, HUD Guidelines recommend testing a designated sample of units to provide 95% confidence that most units are below the lead standard. The sample size should be carefully chosen using statistical techniques (see HUD Guidelines, Table 7.3).

Sample Analysis

Portable XRF devices expose a surface to X-ray or gamma radiation and measure the emission of characteristic X-rays from each element in the analyzed surface. The XRF

reading is compared with a range specified in the PCS for the specific XRF device being used and the specific substrate beneath the painted surface.

When discrepancies exist between the PCS, HUD Guidelines, and the XRF device's manufacturer's instructions, the most stringent guideline should be followed.

Quality Assurance

HUD Guidelines provide several techniques for evaluation of inspection quality.

A knowledgeable observer independent of the inspection firm should be present for as much XRF testing as possible, especially if they have knowledge of LBP evaluation and/or the paint history of the facility.

The client should ask the inspector to provide copies of the results as soon as possible, or daily, allowing for immediate review.

Data from HUD's private housing lead-based paint hazard control program show that it is possible to successfully retest painted surfaces without knowing the exact spot which was tested. Therefore, the client may consider selecting 10 testing combinations for retesting at random from the already compiled list of all testing combinations, using the XRF device used for the original measurements, if possible. The average of the 10 repeat XRF results should not differ from the 10 original XRF results by more than the retest tolerance limit. The procedure for calculating the retest tolerance limit is specified in the PCS. If the limit is exceeded, the procedure should be repeated using 10 different testing combinations. If the retest tolerance limit is exceeded again, the original inspection is considered deficient.

Currently XRF technology and methods are not applicable to PCBs building material evaluation, as the precision is not adequate to provide a concentration that could be relied upon for this program.

1.2.3 LBP Sampling Procedures: Laboratory Testing of Paint Chips

The following sections summarize LBP evaluation procedures for XRF devices, including the description of sampling equipment, collection techniques and frequency, sample analysis, and quality assurance.

Laboratory analysis of paint chip samples is only recommended by HUD for inaccessible areas or building components with irregular (non-flat) surfaces that cannot be tested using

XRF devices, for confirmation of inconclusive XRF results, or for additional confirmation of conclusive XRF results.

Unlike XRF analysis, paint chip collection techniques may be more directly applicable to potential PCBs collection techniques.

Sampling Equipment

Common hand tools can be used to scrape paint chips from a surface; specialized equipment is not necessary. However, HUD Guidelines recommend that samples should be collected in sealable rigid containers rather than plastic bags, which generate static electricity and make laboratory transfer difficult.

Collection Techniques

HUD Guidelines, which are consistent with ASTM E1729, Standard Practice for Field Collection of Dried Paint Samples for Subsequent Lead Determination, recommend that only one paint chip needs to be taken for each testing combination, although additional samples are recommended for quality control.

The paint chip sample should be taken from a representative area that is at least 4 square inches in size. The dimensions of the surface area must be accurately measured to the nearest 1/16th of an inch so that laboratory results can be reported in units of mg/cm². Paint chip collection should include collection of all the paint layers from the substrate, but collection of actual substrate should be minimized. Any amount of substrate included in the sample may cause imprecise results.

Sample Analysis

A laboratory used for LBP analysis must be recognized under EPA's National Lead Laboratory Accreditation Program (NLLAP) for the analysis of lead paint; however, States or Tribes may operate an EPA-authorized lead-based paint inspection certification program with different requirements.

There are several standard laboratory techniques to quantify lead in paint chip samples, including Atomic Absorption Spectroscopy, Inductively Coupled Plasma-Atomic Emission Spectroscopy (ICP-AES), Anodic Stripping Voltammetry, and Potentiometric Stripping Analysis.

For analytical methods that require sample digestion, samples should be pulverized so there is adequate surface area to dissolve the sample before laboratory instrument

measurement. In some cases, the amount of paint collected from a 4-square-inch area may exceed the amount of paint that can be analyzed successfully. It is important that the actual sample mass analyzed not exceed the maximum mass the laboratory has successfully tested using the specified method. If subsampling is required to meet analytical method specifications, the laboratory must homogenize the paint chip sample (unless the entire sample will eventually be analyzed, and the results of the subsamples combined). Without homogenization, subsampling would likely result in biased, inaccurate lead results. If the sample is properly homogenized and substrate inclusion is negligible, the result can be reported as a loading, in milligrams per square centimeter (mg/cm^2), the preferred unit, or as percent by weight, or both.

Quality Assurance

Laboratory reference materials processed with the paint chip samples for quality assurance purposes should have close to the same mass as those used for paint-chip samples (refer to ASTM methods E1645, E1613, E2051, and E1775).

Reporting

The laboratory report for analysis of paint chip samples should include at a minimum, the information outlined in the EPA National Lead Laboratory Accreditation Program Laboratory Quality System Requirements, Revision 3.0, section 5.10.2, Test Reports¹⁵. In addition to those minimum requirements, test reports containing the results of sampling must include specified sampling information, if available.

¹⁵ National Lead Laboratory Accreditation Program: Laboratory Quality System Requirements <https://www.epa.gov/sites/production/files/documents/lqsr3.pdf>, accessed September 20, 2017.

APPENDIX D

Document Revision History

Protocol for Evaluating Priority PCBs-Containing Materials before Building Demolition

Summary of Revisions November 2019

1. The description of currently established building material evaluation protocols for asbestos and lead-based paint were moved from Section 2 to Appendix C.
2. Both window glazing putty and window caulking were added as examples within the “Caulks and Sealants” category to the list of priority materials to sample in Section 2.1.
3. Added clarification in Section 2.1 that sampling of the priority building materials listed in the protocol is required at a minimum. Sampling of building materials coming into contact with priority building materials is not required specifically by this protocol, but may or may not be part of any subsequent remediation. Also clarified that applicants who have conducted sampling prior to the publication of the protocol may use that data provided it is consistent with the protocol.
4. California-ELAP was added to Section 2.2.4 as an acceptable accreditation for a laboratory used to analyze priority building materials for PCBs (in addition to the national NELAP accreditation).
5. Added a clarification to Section 2.2.1 that decontamination with certain solvents (e.g., hexane) may be utilized for cleaning of tar-like substances off of sampling tools, followed with the standard decontamination procedures listed in the protocol. It is recommended that equipment is air-dried, but it is up to the discretion of the environmental professional to use alternative drying methods if time constraints for air-drying are prohibitive.
6. Section 2.2.3 was revised to increase the reporting limit from 50 to 500 micrograms per kilogram and to allow for the reporting limit to be modified to account for necessary dilutions or interferences, as determined by the laboratory.
7. Minor edits were made to the text throughout to correct typographical errors and improve clarity. In addition, clarifying edits to nomenclature were made to the photo log in Appendix B.